




Ski end for  
„Butterfly“



Ski end for  
„K-Clip“



**KOHLA**

#### **Length adjustment for Multifit climbing skin with Elastic Strap**

1. Remove the protective foil from the skin
2. Center the skin on the ski
3. Peel the skin back about 35 cm (14") from ski tail
4. Place the jig between skin and ski tail, using marks to guide you. Pay attention to the appropriate mark for the ski end
5. Stick the skin onto the already positioned jig
6. Remove the skin from the ski with jig
7. Fold the strap along perforated line backwards
8. Cut the skin along line, closely following the jig
9. Remove the jig from the skin and repeat these steps with your second skin

#### **Längen Anpassung Multifit Fell mit Elastic Strap**

1. Entfernen Sie die Schutzfolie des Felles
2. Positionieren Sie das Fell mittig auf den Ski
3. Ziehen Sie das Fell wieder ca. 35 cm vom Skiende ab
4. Positionieren Sie die Schablone den Markierungen nach zwischen Belag und Fell mittig am. Achten Sie dabei auf die entsprechende Markierung für das Skiende.
5. Kleben Sie das Fell auf die bereits ausgerichtete Schablone
6. Entfernen Sie das Fell zusammen mit der Schablone vom Ski
7. Klappen Sie die Lasche entlang der perforierten Linie nach hinten
8. Schneiden Sie das Fell gemäß der Schablone zu
9. Schablone vom Fell abziehen und Vorgang mit dem zweiten Fell wiederholen

#### **Check out our instruction videos**

[www.kohla.at/de/Services/Kohla-Service-Videos/](http://www.kohla.at/de/Services/Kohla-Service-Videos/)

140

130

120

110

100

100

110

120

130

140