

HAPPY EMOTION

CHILDREN CARRIER

INFORMATION

FEATURES

- Adjustable carrying system allows for easy adjustment to back length
- Thickly padded roll bar stabilises the child's head
- Large luggage compartment (18 l capacity)
- Small luggage compartment removable
- Sun canopy or simple rain canopy integrated in the backrest
- Very sturdy aluminium frame
- Soft cushion, removable & washable
- 3-point harness with soft padded straps
- Padded hip belt with pocket
- Integrated rear view mirror
- Adjustable leg straps
- Usable up to approx. 24 kg
- Weight: approx. 3000 g

SECURITY INFORMATION

- Attention: The stretcher is for infants, who are not yet able to hold themselves upright and sit independently.
- The maximum payload is 24 kg including luggage.
- The stretcher is self-standing. But please make sure that it is level. Do not leave your child unattended in the carrier.
- Before putting the carrier on, check that all straps are correctly fastened and that your child is in a comfortable sitting position. In general, ONLY transport the child with the seatbelt fastened!
- Take breaks! Sitting for long periods of time can affect blood circulation, especially in the legs, and can lead to frostbite or damage in cold temperatures.
- Make sure you have suitable weather protection and clothing. Because of the restricted movement, your child will freeze faster than you. Make sure your child is protected from the sun.


WARNING

- Only children may be carried in the Kohla child carrier by adults.
- Before each use, check the carrier for damage and never use it if it is damaged.
- Pay careful attention to the child's legs and head of the child. It is easy for objects to come into contact with them and cause injury.
- Take extra care when leaning forward and when picking up and putting down the carrier.
- The Kohla child carrier is only suitable for leisure activities, but not for sports such as cycling, skiing or similar.
- Failure to observe these warnings may result in serious injury or even death to the child.

CARRYING SYSTEM



Before you start fitting, loosen all the straps.



To adjust the shoulder straps to your body size, open the tab on the back system.



There is a tension belt underneath.



Tall people pull the system upwards, shorter people can adjust the system downwards using the tensioning strap.



You can adjust the back system to different heights.



Now tighten the shoulder straps.



Also tighten the load straps at the top so that everything fits well.



Close the waist belt so that it sits well on your mid-pelvic bone and the main weight is on your hip.


CHILD SEAT



Open the side wing.



To adjust the child seat, pull up on the adjustment loop or loosen it down.



Put the child inside and fasten the child harness.



Close the side wing again and tighten the strap.



Adjust the footrests to the appropriate height using the carabiner.

KOHLA

HAPPY EMOTION

CHILDREN CARRIER

ROOF



The roof is integrated into the backrest. To put it up, open the zip on the backrest.



Pull out the roof.



Attach the roof to the front of the stretcher with the straps.


PICKING UP THE CHILD CARRIER




Fold the stand bar backwards, as in the next picture.




Note: If you are hiking alone, leave the carrier in the „standing“ position to ensure easy picking up and putting down.



Hold the stretcher firmly by the main handle.




Slip one arm into the shoulder strap and take the weight on that side.




Fix all the straps again and then you're ready to go.

PUTTING DOWN THE CHILD CARRIER



For putting down, take the main handle in your hand.



Thread one arm out of the strap.



Put down the carrier carefully and please make sure that you place it on a even surface.



Note: If you are hiking alone, leave the carrier in the „standing“ position to ensure easy picking up and putting down.



Note: If the stand bar is folded in, ask someone to unfold the stand bar before parking.