

KOHLA

HAPPY EMOTION LIGHT

CHILDREN CARRIER

INFORMATION

FEATURES

- Removable sun or rain roof
- Soft chin pad, removable
- Spacious 18ltr large bottom compartment
- Height adjustable seat
- Very stable aluminium frame
- High quality backpack carrying system
- Stable handlebar
- Padded hip belt with pocket
- Integrated rear view mirror
- Adjustable leg straps
- Reflective stripes
- Optional rain cover
- Usable up to approx. 18 kg
- Weight: approx. 2100 g

SECURITY INFORMATION

- **Attention:** The children carrier is for infants, who are not yet able to hold themselves upright and sit independently. The maximum payload is 18 kg including luggage.
- The children carrier is self-standing. But please make sure that you place it on an even surface. Do not leave your child unattended in the carrier.
- Before putting your child in the carrier, check that all the straps are correctly fixed and that your child is in a comfortable sitting. In general, **ONLY** transport the child with the seatbelt fastened!
- Take breaks! Sitting for long periods of time can affect blood circulation, especially in the legs, and can lead to frostbite or damage in cold temperatures.
- Make sure you have suitable weather protection and clothing. Because of the restricted movement, your child will freeze faster than you. Make sure your child is protected from the sun.

WARNING

- Only children may be carried in the KOHLA child carrier by adults.
- Before each use, check the carrier for damage and never use it if it is damaged.
- Pay careful attention to the child's legs and head of the child. It is easy for objects to come into contact with them and cause injury.
- Take extra care when leaning forward and when picking up and putting down the carrier.
- The Kohla child carrier is only suitable for leisure activities, but not for sports such as cycling, skiing or similar.
- Failure to observe these warnings may result in serious injury or even death to the child.


CARRYING SYSTEM



Before you start fitting, loosen all the straps.



Now tighten the shoulder straps.



Also tighten the load straps at the top so that everything fits well.



Close the waist belt so that it sits well on your mid-pelvic bone and the main weight is on your hip.

CHILD SEAT



Open the straps of the child seat.



To adjust the child seat, pull up on the adjustment loop or loosen it down.



Put the child inside and fasten the child harness.




Next, tighten the straps so that your child sits well.



You can open the side wing so that the child can sit in comfortably.



Fix the side wings.



Adjust the footrests to the appropriate height using the carabiner.



There are three heights for the footrests.

ROOF



You can hang the sun canopy in the place provided for it.



Push the roof all the way down so that it cannot slip ...



... and fix it with the straps.

KOHLA

HAPPY EMOTION LIGHT

CHILDREN CARRIER

PICKING UP THE CHILD CARRIER



Fold the stand bar backwards, as in the next picture.



Note: If you are hiking alone, leave the carrier in the „standing“ position to ensure easy picking up and putting down.



Hold the stretcher firmly by the main handle.




Slip one arm into the shoulder strap and take the weight on that side.




Fix all the straps again and then you're ready to go.

PUTTING DOWN THE CHILD CARRIER



For putting down, take the main handle in your hand.



Thread one arm out of the strap.



Put down the carrier carefully and please make sure that you place it on a even surface.



Note: If you are hiking alone, leave the carrier in the „standing“ position to ensure easy picking up and putting down.



Note: If the stand bar is folded in, ask someone to unfold the stand bar before parking.